MANUAL

EM6570 - e-Domotica door contact

WWW.EMINENT-ONLINE.COM

EM6570 - e-Domotica door contact

Warnings and points of attention

Due to laws, directives and regulations set out by the European Parliament, this device could be subject to limitations concerning its use in certain European member states. In certain European member states the use of this product could be prohibited. More information regarding this warning can be found in the Declaration of Conformity on the last page of this document!

Table of contents

1.0 Introduction 2
1.1 Functions and features 2
1.2 Packing contents 2
2.0 Using the door contact 3
2.1 Assign the door contact to the Eminent e-Centre 3
2.2 Adding the door contact to the already installed e-Centre 3
2.3 Mounting the door contact 4
2.4 Removing the door contact 4
3.0 Frequently asked questions 5
4.0 Service and support 5

1.0 Introduction

Congratulations with the purchase of this high-quality Eminent product! This product has undergone extensive testing by Eminent's technical experts. Should you experience any problems with this product, you are covered by a five-year Eminent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.eminent-online.com and receive product updates!

1.1 Functions and features

Connect the EM6570 wireless door contact to your window, door or other objects which can be opened and closed. Connect the door contact to your Eminent e-Centre. Your e-Centre will 'see' if a door or windows opens, because the moment this happens, the door contact will broadcast a wireless signal to your e-Centre. Combine the door contact with your e-Centre and create a security system nobody can ignore!

1.2 Packing contents

The following parts need to be present:

- EM6570 wireless door contact
- Magnet with double-sided tape
- 3x AAA batteries
- User manual

2.0 Using the door contact

Only a few short and simple steps are necessary to mount the door contact to your door or window and assign the door contact to your e-Centre and let the functioning of the EM6570 begin. Use the following steps to connect the door contact.

2.1 Assign the door contact to the Eminent e-Centre

There are two possible situations when assigning the door contact to the Eminent e-Centre.

1. You assign the door contact to the Eminent e-Centre during the installation process of the e-Centre itself. The installation wizard of the e-Centre will move along the 9 steps during the installation process of the e-Centre itself, meaning you can add all your e-Domotica devices through the e-Centre's own website. For this installation you have to follow the steps shown on screen. Use the metal button at the back of the door contact during the installation procedure.
2. You can add your door contact to the already installed e-Centre. This is described in chapter '3.2 Adding the door contact to the already installed e-Centre'.

2.2 Adding the door contact to the already installed e-Centre

1. Take the door contact out of the packaging. Make sure the door contact is in close range with the e-Centre (30 centimeter maximum)

When assigning the door contact, a shorter distance is required compared to being in service.

2. Carefully unscrew the bottom of the door contact and carefully slide the lid off the door contact in order to open the battery compartment.
3. The battery compartment is now open. Insert the supplied AAA batteries into the battery compartment. Do not yet place the lid back!
4. Make sure your computer is completely started.
5. Open your computer's web browser.
6. Fill in "http://e-Centre" in the address bar of your web browser and press the 'Enter' key on your keyboard.

7. The openings screen of the Eminent e-Centre will be shown.
8. Click the ‘Add’ button, the e-Centre will start to search for new e-Domotica devices.
9. Press the button on your new door contact (at the back of the door contact).
10. A message will appear: ‘Product found’.

If the device is not found, press the ‘Reset’ button in the e-Centre’s webpage and then click the button on your door contact. After this procedure you can add the new device correctly.

11. Give the connected and found device a name and a give a location, and click ‘Save’.
12. The door contact has now been added to the e-Centre. The e-Centre can now communicate with the door contact.

Note: In order to use the alarm function, we refer to the users manual of the Eminent e-Centre.

2.3 Mounting the door contact

1. Use the lid you have just removed to mark the spot where you want to mount the door contact. For example, place the door contact on the frame. Do not place the door contact (the largest part of the EM6570) on the moving part of the window or door.
2. Mount the lit on the frame.
3. Place the door contact onto the lid which you have just mounted. Carefully screw back the little screw at the bottom of the door contact. Do not over tighten the screw to prevent damage to the door contact.
4. Use the double-sided tape to mount the supplied magnet next to the door contact, at the moving part of the window or door. You have to mount the magnet next to the door contact, make sure the space between the door contact and magnet lies between 2 till 10 mm. Also make sure the horizontal lines on both the door contact and magnet are leveled!

If the door contact is placed at a distance of more than 25 meters, you can now place the door contact at the desired location. Choose ‘e-Domotica devices’ in the e-Centre’s webpage, then choose the ‘Optimize’ option. By doing so, your wireless network will be optimized for maximum range.

2.4 Removing the door contact

1. Make sure your computer is completely started.
2. Open you computer’s web browser.
3. Fill in “http://e-Centre” in the address bar of your web browser and press the ‘Enter’ key on your keyboard.

4. The openings screen of the Eminent e-Centre will be shown.
5. Click the ‘Remove’ button.
6. Press the button on your door contact.
7. The device has now been deleted.

3.0 Frequently asked questions

Q: What is the maximum wireless range of my e-Domotica devices?

A: Thanks to the network’s repeating option (amplifiers), the wireless range of the e-Domotica devices is virtually unlimited. Both the EM6550 switch and the EM6551 dimmer act as a repeater. Without repeating, the maximum wireless range indoor is approximately 25 meters. You can optimize the wireless range by adding an extra EM6550 switch or EM6551 dimmer, and then use the ‘Optimize’ function in the e-Centre’s webpage.

Q: I have mounted the door contact to a metal frame. Is looks like the wireless signal is not sufficient enough to reach the e-Centre?

A: Contact with bare metal can disrupt the wireless signal in such a way, that the wireless reach is limited. Make sure you do not mount the door contact to bare metal, but use a plastic bedding for optimal wireless range.

Q: Why does the light on the door sensor blink slowly?

A: This means that the door contact is not yet linked to the e-Centre. The moment the door contact is linked to the e-Centre, the light will turn off.

4.0 Service and support

This users manual has been carefully written by Eminent’s technical experts.
If you have problems installing or using the product, please fill out the support form at the website www.eminent-online.com/support.

Warranty conditions

The five-year Eminent warranty applies to all Eminent products unless mentioned otherwise before or during the moment of purchase. When having bought a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's first owner.
The Eminent warranty applies to all Eminent products and parts inextricably connected to and/or mounted on the main product. Power supply adapters, batteries, antennas and all other products not integrated in or directly connected to the main product and/or products of which, without reasonable doubt, can be assumed that wear and tear show a different pattern than the main product are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when subjected to incorrect/improper use, external influences and/or when opened by parties other than Eminent.

Declaration of Conformity

To ensure your safety and compliance of the product with the directives and laws created by the European Commission you can obtain a copy of the Declaration of Conformity concerning your product by sending an e-mail message to: info@eminent-online.com. You can also send a letter to:

Eminent Computer Supplies
P.O. Box 276
6160 AG Geleen
The Netherlands

Clearly state 'Declaration of Conformity' and the article code of the product of which you would like to obtain a copy of the Declaration of Conformity.

EMINENT

WWW.EMINENT-ONLINE.COM

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.
The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.

CE

Eminent is a member of the Intronics Group